# (A) 0 0

### 产品特点

- 1. 外形美观、体积小巧, 携带方便
- 2. 兼容苹果手机线控功能
- 3. 操作语音提醒,更贴心
- 4. 内置时钟芯片,录音文件名以时间命名,便于精确查找
- 5. 录音可直接播放给对方听, 也可传输至手机保存
- 6. 可通过USB连接电脑将录音文件拷贝出来
- 7. 标配512MB存储,16小时超长录音(有容量增加需求的 以增加后的容量为准)
- 8. 内置200mAh锂电池,连续录音时长达5小时

### 产品参数

1.工作电压:5V 2. 売体材料: ABS

3.录音由流: <40mA 4.播放电流: ≤50mA 5.休眠电流: ≤10uA


6. 充电电流: ≤200mA 7.线长: 1.2M ±5%

8.端口: 3.5mm

9.耳机外壳: ABS塑胶/铝合金 10.MIC灵敏度: -42dB全指向

11.使用环境:仅限于室内使用,相对湿度小于95%

### 设备接口介绍



### 工作指示灯功能说明

1.录音讨程中纤灯闪烁 2.播放过程中红灯长亮


3.删除录音时红灯快速闪烁3次

4.无任何操作状态下红灯快速闪烁为内存满,自动删除文件

5.电量不足时每次播放完成后红灯闪烁5次。

1.充电时长高:

2.充满时熄灭.



## 录音时间更新

按键功能说明

- 初次使用本产品请先更新内置时间与当前时间—— 到 以便干 您日后精确的查找录音文件。
- 在电脑桌面上新建一个"记事本",将名称改为"TM",打开文 档,输入当前的年月日时分秒,如20170119191919,代表 当前设定的时间为2017年1月19日19时19分19秒,保存文 件,将耳机插上电脑,将此文件单独拷贝至耳机内
- 拔掉USB线,此时本产品自动更新当前时间,并自动删除该 文档.

### USB充电

采用Micro USB接口充电,配备USB线。

### 文件导出

长按

拷贝:使用USB线连接电脑会自动识别到可移动磁盘,此 时可将磁盘内的录音文件拷贝出来

反录:打开手机,白带录音机, 也,可下载手机,录音软件 (VoiceRecoder),播放录音录回至手机讲行存储

### 循环录音说明

当内存小于50M时会自动删除最早的文件,以文件名顺序 开始删除

### 休眠说明

当无任何操作3秒后产品会自动进入休眠模式,当按下录音 键时会立即进入工作状态;休眠时开启录音会有3秒钟的延 时、屋正堂现象。

### 使用注意事项

- 使用耳机时请注意控制适当的音量,以免损伤听觉。
- 请勿用力拉扯耳机线,以免出现断裂现象.
- 在高温高湿的场所长时间使用耳机,容易造成耳机损坏 或使用寿命降低。
- 驾驶汽车、骑自行车或马路上行走时,请勿使用耳机, 否则容易导致交通意外.
- 请将耳机放在儿童接触不到的安全地方,以防发生危险。 ■ 使用频繁时,请及时给耳机充电,以免影响正常使用。
- 充电时间请勿过长,充满电请及时拔掉充电头.
- 存储时请勿将电量耗尽,否则可能造成电池损坏。

### 产品内部操作说明

- ■只要开启录音,必须录3秒才会停止,以方便进行按键上 下曲操作,请勿在开启录音后立即结束录音
- ■录音结束后,系统会自动查询当前剩余容量,如立即按键 按下播放,可能会出无反应的情况,请在结束录音1秒后 再进行按键操作.
- ■产品在用户未进行任何操作时自动进入休眠以节省电量 当从休眠情况下唤醒时会延时3-4秒才会执行对应的动 作,如开始录音或开始播放,请耐心等待,不要重复进行 按键操作
- ■本产品仅支持iPhone4及以上版本手机的线控功能,因上 下曲按键为一键多用,在插入手机时请不要让本产品处于 播放状态,否则会造成线控功能无法正常使用,此时需要 拔下耳机,重新插入即可正常控制
- ■通话录音结束后, 试听录音时请拔下耳机, 不要与手机连 接,苹果手机的音频输出信号会与本产品的录音播放信号 重叠导致本产品音质变差,声音变小,
- 当录音声音较小时,请在通话时将手机的通话音量加大.

### Features

- 1. Small size, easy to carry.
- 2. Compatible with the line control feature of iPhone.
- 3. It has the voice prompt during operation.
- 4. Built in clock chip, the recording files named according to

for convenience to seek


- 5. Can play the recording, store the recording into the phone.
- 6. Can copy the recording files out from earphone connected to computer via USB cable.
- 7. Built in 512Mb memory, recording duration up to 16 hours. (Can customize the capacity if you need.)
- 8. Built in 200mAh lithium battery, continuous recording up to 5 hours.

### Parameters

- Working voltage: 5V
- 2. Shell material: ABS
- 3. Recording current: ≤40mA
- Plaving current; ≤50mA
- Sleep current; ≤10uA
- Charging current: ≤200mA
- 7. Cable length: 1.2M ±5%
- 8. USB port: 3.5mm
- 9. Earphone shell: ABS plastic/ aluminum alloy
- 10. MIC sensitivity: -42dB omni response

11. Environment: indoor use, relative humidity less than 95%

# Appearance introduction



### Working indicator light

- - USB port

- 5. When the battery is insufficient, each time finish playing, the red light will flash 5 times.
- Light off when full charged.

L× Deleted

∀ Next

# Key function description

	Short Press	Long Press
₽	Play the final recording, if you switch to the previous or next recording, it will memorize the final recording automatically. Short press to stop when it is playing.	Long press this key 2s, release it after hearing voice prompt, then it will start recording. Short press again, it will end the recording after hearing the voice prompt.
	ю рюунту.	Delete all recordings: press this key and the key 'Next' or 'Previous' for 3s simultaneously.     When the red light shines 3 times and hearing the voice prompt, delete successfully.
8	Its function is the same with the answer key of the line control earphone	Its function is the same with the answer key of the line control earphone
<b>()</b> ) ≅ ※	When not playing, it is line control function and volume up.	Long press the key for 3s to delete the current recording you are listening.
	When playing the recording, press it to play the previous one.	Delete all recordings: Press this key and the recording ke for 3s simultaneously.
<b>⊕</b> ≅	<ol> <li>When not playing, it is line control function and volume down;</li> </ol>	Long press the key for 3s to delete the current recording you are listening.
	When playing the recording, press it to play the next one.	Delete all recordings: Press this key and the recording ke for 3s simultaneously.

### Recording Time Update

- In order to search for the recording files exactly in future. please update the built-in time in line with the current time.
- Creating a 'new notepad' on your computer desktop. change the name into 'TM', open the document, input the current time of YYMMDDHHMMSS, such as 20170119191919, it means the current time setting is at19:19 on January 19th, 2017, 19 seconds
- Then save the document, connect earphones to the computer, copy this document into earphones solely. Pull up the USB cable, now this product will update the current time and delete the document automatically.

### USB charging Charge through micro USB port. Provide free USB cable.

### File export Copy: Use USB cable to connect computer, it will

automatically recognize the removable drive. At this time, you can delete or copy out the files of this removable drive.

Record back: Open phone recorder, press the "Play" key to play the recording, then the recordings will be stored into your mobile phone.

### Loop recording

When the memory is less than 50M, it will automatically delete the earliest files, deleted in file name order.

### Sleep mode

When there is no any operation, 3 seconds later, it will automatically enter the sleep mode. When press the record key, it will start to work immediately. In the sleep status, when you enable the recording, it will have 3s delay, that's normal

#### Using notes

- When using, pay attention to control the volume, so as not to damage the hearing.
- Do not force pull the earphone cable, or it may be
- damaged In the environment of high temperature and high humidity
- use earphone for a long time, easy to cause damage to the earphone or reduce its service life. ■ When driving a car, riding a bicycle or walking on the road, don't wear earphone, otherwise easily cause traffic
- accidents. ■ Please keep the earphone out the reach of children, in case
- Please timely charge, so as not to affect the normal use. ■ Charging time should be not too long. When full charged,
- Avoid the battery run out. At least charge once every 3 months, otherwise may cause permanent damage to the

### Operation instruction ■ When enable recording, can't stop unless record 3s. Please

- don't end the recording immediately after starting recording. ■ When the recording ends, it will automatically guery the
- immediately, there may be no reaction. Please operate 1s later when the recording ends.
- It will enter the sleep mode to save power when there is no operations. There will be 3~4s delayed to work when wake from the sleep status. Please wait patiently. Don't repeat
- This product only supports the line control function of iPhone 4 and above version. Since the keys are multipurpose, when inserted into the phone, please don't let this product in the state of play, otherwise it will cause line control function invalid. At this time, please remove the earphone, and insert again, then this function can be normal.
- After finishing recording the call, please remove the earphone when you listen to the recording. Don't connect to the phone. Otherwise, that will cause the sound quality worse and volume decreasing.
- When recording volume is small, you can increase the volume on your mobile phone.

# 质量保修卡

丽室姓夕:

产品刑号

制作编号:	 顾客地址:	
购买日期:	 顾客电话:	
购买公司:	 E-Mail :	
公司电话:	 邮 编:	

注:锂电池保修期为3个月,如超过保修期,更换电池需要收取相应的费用。

#### Warranty Card

roduct model:	Customer name:
roduction number:	Customer addre
urchase date:	Customer phon
uyer company:	E-Mail:

charge fees to replace the battery; other components warranty is 1 year, except the artificial damage.

Post code: